



Water Fall bath enclosures

Model 64 & 65 Framed Two Panel Sliding Enclosure Installation Instructions




Installation Tools Required: Tape Measure, Masking Tape, Level, #2 Phillips Screwdriver, Flat Screwdriver, Drill with 1/8", 7/64" and 3/16" bits, hacksaw, pencil, clear silicone caulking. Optional: Miter Box, File and Center-Punch.


1 Measure the wall-to-wall opening at the center of the tub rim or shower curb. Cut the Track (A) 1/16" short of this dimension. Center the Track as shown and use masking tape to mark the edges and secure to the tub or shower




3 Remove the parts and drill 1/8" holes approximately 1 inch deep in each wall in the marked locations. In tile or marble walls, it may be necessary to drill 3/16" holes and insert the plastic Wall Plugs (C). Using a caulking gun and a good grade of silicone, run two continuous beads of sealant inside the masking tape and inside the corners. To ensure a tight fit, force a slight downward bow in the Tub Track. Carefully replace the track and press firmly into the sealant.



2 Press each of the Wall Jamba (B) over the ends of the Track. Plumb the Wall Jamba with a level and secure with masking tape. Use a pencil to mark the locations of the three holes in each Wall Jamba. If necessary, use a file to round the corners of the Wall Jamba and Curb to match the wall conditions.




4 Replace one Wall Jamba and attach to the wall with two #8 x 1-1/2" Truss Head Screws (D) through the top and bottom holes. Press a Nylon Spacer (E) over a third screw and install in the center hole. Check for plumb before tightening the screws.




5 Measure the wall-to-wall opening at the top of the wall jambs. Cut the Header (F) 1/16" short of this dimension and check for fit.

Slide the header over the tee-lock on the mounted wall jamb. Pivot the header to clear the opposite wall and slide the tee-lock of the remaining wall jamb into the header. Pivot back into position and press the bottom of the wall jamb over the track. Attach the jamb to the wall as noted in Step 4.



6 For units glazed with obscure glass, identify the interior and exterior panels. Rollers on the exterior panel are installed on the same side as the textured surface of the glass. Rollers on the interior panel are installed on the smooth side of the glass. For ease of cleaning, obscure glass is always installed with the textured surface to the exterior of the unit.


Standing outside the tub or shower, lift the interior panel into the header as shown and position the rollers into the track in the header. Repeat for the exterior panel. Check for ease of operation and determine if the panels are parallel to the wall jambs. If the panel does not line up with the wall jamb, remove and adjust the rollers in the diagonal slot for proper alignment.



7 For maximum protection from over-spray and leakage, the interior panel should always be installed closest to the shower head. Properly installed, the Finger Pulls (G) and Bumpers (H) prevent the panels from reversing from this position.


Note there are four bumpers included. If the shower head is on the right, use the two bumpers with the letter "A" embossed on the back. If the shower head is on the left, use the bumpers marked "B".

Reference this illustration for proper orientation of the towel bars, finger pulls and bumpers in the following steps.




8 Press a Towel Bar Bracket (G) into each end of the Towel Bar (H). Slide a Sleeve (I) over each bracket. Attach the assembled towel bar to the center rail with a #10 x 7/8" Truss Head Screw (J).


Press a #10 x 1-1/8" Flat Head Screw (K) through the Finger Pull (L) and attach to the remaining towel bar bracket. Peel the protective backing off the Waterfall Label (M) and apply into the recess in the finger pull to cover the head screw.




9 Install the appropriate bumper (A or B as described in Step 7) by pressing the larger portion of the "keyway" over the head of the center screw and spacer installed in Step 4. Slide the bumper down the surface of the wall jamb approximately 3/8" to lock into position.



10 Located the Bottom Guide (N) in the center of the track with the interior panel positioned as shown. Drill a mounting hole in the Track with a 7/64" bit using the hole in the guide and the V-groove in the track to locate properly. Attach with a #6 x 3/8" Pan Head Screw (O).



11 Using a caulking gun (Step 3) run a bead of clear silicone along the interior of the wall jambs and track as shown. Seal the intersection of the wall jambs and the track as shown. Allow the silicone to dry for 24 hours before use.



Clean your new Waterfall Enclosures with a soft cloth and a non-abrasive cleaner with a neutral Ph. Do not use acid based cleaners, vinegar or scouring pads to clean your unit.